

3 year
Gold
Warranty

AQUA ADVANCE INDUSTRIES PTY. LTD.

(Incorporated in NSW)

ABN 69 002 044 402

ACN 002 044 402

WATERBED HEATER

WARRANTY – 3 YEAR FREE REPLACEMENT.

- Aqua Advance Pty Ltd Heater Units are warranted to be free of defects in material and workmanship.
- Aqua Advance Industries Pty Ltd will repair or replace any defective part or parts which occur within three years following the original date of purchase.
- This warranty will only apply to the original purchase from an authorised retail outlet.
- Defective parts should be returned PREPAID to AQUA ADVANCE INDUSTRIES PTY. LTD., PO Box 6467, Wetherill Park 2164.
- Transport, freight or shipping costs are not included in this warranty.
- This warranty shall not apply where it is considered by the manufacturer that all or any part of the Heater Unit has been subjected to unreasonable use OR there has been failure to provide reasonable and necessary care.
- This warranty is in addition to all other rights in respect of the product bestowed upon the consumer by the Trades Practices Act and similar states and territory laws.
- **DISCLAIMER** – This warranty and the obligations of AQUA ADVANCE INDUSTRIES PTY LTD does not extend to incidental and/or consequential damages resulting from use or misuse of the AQUA ADVANCE INDUSTRIES PTY LTD Heater Unit.

**KEEP THIS CARD TOGETHER WITH YOUR SALES DOCKET
IT MUST BE PRODUCED FOR ALL WARRANTY CLAIMS**

WARNINGS - CAUTION Please read instructions carefully

- This heater is designed only for use in waterbeds.
- Do not insert sharp objects into control or pad.
- Observe all instructions carefully to avoid risk of fire or shock.
- Avoid folds and creases in waterbed mattress and safety liner in contact with heater.
- Only the safety liner and mattress must be in contact with the upper surface of the heater pad.
- Any other materials such as foam overlays, blankets or any object whatsoever will create heater pad problems and this warranty will be void.
- The 350 watt heating pad should be used under waterbeds with 5 inches minimum depth (127mm) and a top surface area of not less than 1.36 square metres.
- If the heater is intended to be mounted on an insulating or foam base the heater pad shall be positioned on a firm flat base of minimum thickness of 4.5mm hardboard which has dimensions such as to provide a marginal overlap of at least 50mm right around the heating pad and that the hardboard should be smooth.
- Do not crease or fold heater pad.
- All waterbed heaters must be placed on flat hard surfaces. Do not place over joins, cracks or drill holes. the surface must be flat and unimproved.
- Whenever you move the bed it is suggested that you have your heater serviced by the nearest service centre.
- This heater is not to be used under tubular Mattresses.

INSTRUCTIONS

- To be read in conjunction with instructions on heater pad.
- **DO NOT PLUG CONTROLLER INTO POWER SOCKET UNTIL BED IS FILLED WITH WATER.**
- Place the heater pad on the decking board, not closer than 300mm or 30 cm to the frame. Ensure that the heater pad is flat. The heater pad may be placed down either side, across the head or across the foot of the decking. ensure that all instructions made in the note "WARNINGS" are followed.
- Ensure that no foam or any other material comes into contact with the surface of the heater pad.
- Take the heater cord out of the frame cavity through the accommodating hole at the top corner of the decking.
- Install your AQUA ADVANCE PTY LTD liner and water mattress per the AQUA ADVANCE PTY LTD instructions. **MAKE SURE THAT THERE ARE NO CREASES AND FOLDS IN THE LINER OR MATTRESS VINYL IN CONTACT WITH THE HEATER.**
- Fill the mattress with cool water; smooth out creases and folds over the heater pad.
- Plug the heater cord into the control unit then into the power socket.
- For faster heat up times, set the dial on Warm. Leave for three days, then adjust down to suit personal comfort. the heater is working correctly when the control light continues to switch on and off.
- **IMPORTANT NOTE**
THE WATERBED HEATER DOES NOT REACT LIKE AN ELECTRIC BLANKET. THE TIME LAPSE TO WARM OR COOL THE BED, COULD BE SEVERAL HOURS.
- **DO NOT BOTTOM OVER THE HEATER PAD.**
- Save energy costs. Keep your bed covered at all times.

DRAINING BED FOR ANY REASON FIRST UNPLUG THE CONTROL

- **FOR ANY FURTHER ADVICE OR INFORMATION, CONTACT YOUR LOCAL WATERBED RETAILER.**

COMPLETE THIS CARD TO VALIDATE YOUR WARRANTY
AND MAIL WITHIN SEVEN (7) DAYS OF PURCHASE.
PLEASE PRINT

Surname:.....

Given Name(s):.....

Address:.....

.....State:.....Postcode:.....

Purchased from:.....Purchase Date:.....

Do you have friends with waterbeds?

Under 25 Yrs Under 35 Yrs Under 45 Yrs Under 55 Yrs Over 55 Yrs

Married:..... Children:.....